

6' Vertical Vinyl Hybrid Fence, 8' panels



Installation Instructions

8' x 6' High Elite Plus Fence Panel Instructions

1. Set post in concrete in holes 8" in diameter, 48" deep, centred 96-3/4" apart. For a 6' high fence make sure you have at least 78 1/4" of post above ground your grade level. 74 1/4" of board & pocket channels + 2" up from grade + 2" to top of post = 78 1/4". If you feel you need a few more inches for slope add it or we suggest some longer posts for this purpose. **IMPORTANT: Seal of the top of your posts once they are set. Rain water in here is not your friend.**
2. Mark and level your grade on your posts 2" up from the ground. If your property slopes, you will step your panels from highest to lowest, levelling each panel.
3. Fasten the 3" Pocket Rail with 1 self tapping screw at each end, groove up, bottom flush with the marks you made. Once your panels are done you can fasten the 2nd screw at each end. Just helps if you have to adjust anything, you are not making additional holes.
4. Insert your 6" x 70" PVC boards, left to right. 16 boards in all.
5. Fasten the 3" Pocket Rail with 1 self tapping screw at each end, groove down, leave 1/4" gap from the top of your boards to allow for expansion.
6. Measure 2" up from the top of the 3" Pocket Rail, square it off and cut of the excess. Place you Pyramid Cap on top of each post.
7. Install 2nd Self Tapping screw into bottom rail at both ends, and the same for the top.

